



Resistivity measurements using the Syscal Switching systems

Subsurface Geophysical Solutions
Website: <https://sgs4d.com>
Email: dimitris@sgs4d.com



- Step 1 – Survey configuration

- Although surveys can be configured on the syscal instruments, it is recommended that the survey(s) are prepared in advance using Electre Pro and uploaded to the system.
- Then upload to Syscal (through Electre Pro)
- See demonstration [video](#)




General considerations

For more details see attached 'summary of operation' document

Resistivity measurements using the Syscal Switching systems

Subsurface Geophysical Solutions
Website: <https://sgs4d.com>
Email: dimitris@sgs4d.com




- Step 2: In the field
 - Lay down the cable and insert electrodes in the ground at the desired distance (e.g. every 5 m)
 - Connect the cable leads to the electrodes using the crocodile clip cords



General considerations



For more details see attached 'summary of operation' document

Resistivity measurements using the Syscal Switching systems



- Step 2: In the field

- Lay down the cable and insert electrodes in the ground at the desired distance (e.g. every 5 m)
- Connect the cable leads to the electrodes using the crocodile clip cords
- The SYSCAL is placed in the middle part of the survey line if multiple cables are being used.
 - If one cable is being used, the syscal system can be placed at either end of the cable




General considerations

For more details see attached 'summary of operation' document

Resistivity imaging using the Syscal Switching systems

Subsurface Geophysical Solutions
Website: <https://sgs4d.com>
Email: dimitris@sgs4d.com



- Step 2: In the field

- The metallic electrodes have to be inserted into the ground deep enough to decrease the ground resistance, for both the transmitting electrodes A, B, and the receiving electrodes M, N.
- A resistance of a few kohms is typically fine (< 20 kohm max, < 5 kOhm preferred).
- If needed, conductive water can be poured on the electrodes, or two electrodes can be set in parallel at each point to decrease this value.

General considerations


For more details see attached 'summary of operation' document

Resistivity imaging using the Syscal Switching systems


General considerations

For more details see attached 'summary of operation' document

Subsurface Geophysical Solutions
Website: <https://sgs4d.com>
Email: dimitris@sgs4d.com



- When the measurement becomes noisy (standard deviation Q greater than 5%), it is recommended to:
 - decrease the ground resistance of the A, B electrodes
 - drive more current,
 - to increase the number of stacking,
 - and to repeat several times the same reading.
- **Rule of thumb:**
 - **The depth of investigation is of the order of 20% of the length of the AB line.**



General considerations

For more details see attached 'summary of operation' document

Resistivity imaging using the Syscal Switching systems

SUMMARY OF OPERATION

First reading :

1)connect Cables

2)check batteries – Press Battery (8)

1) If connected to external battery for Tx flip switch to Ext (otherwise to Int)

A full charge will indicate: 12.7 V – 100%


A null charge will indicate: 10 V – 0%



R1+ keyboard panel

Resistivity imaging using the Syscal Switching systems

Subsurface Geophysical Solutions
Website: <https://sgs4d.com>
Email: dimitris@sgs4d.com



General considerations

For more details see attached 'summary of operation' document

Details **Set Up:**


- Mode – select Multi Electrode
- Select a pre-uploaded sequence
- If needed select:
 - stack number – typical Min:4 Max:8
 - Qmax: 5%
 - Tx parameters: select Rho
 - Time: typical 1 or 2s
 - Vp requested –select 800mV (or Max)
 - Alternatively you can select select Vab Max: 50 (based on your electrode spacing and the conditions)



R1+ keyboard panel

Resistivity imaging using the Syscal Switching systems

Subsurface Geophysical Solutions
Website: <https://sgs4d.com>
Email: dimitris@sgs4d.com



General considerations

For more details see attached 'summary of operation' document



After setting up (once per survey)

Protocol for each measurement (Wenner):

- 1) check electrodes, (press Rs Check – 6)
- 2) Press start
 - 1) Follow prompt



R1+ keyboard panel



Menu button (reset to main menu)

Start survey button

Arrows to navigate menu

Return/enter button